



# JACK DADDY

Installation Instructions

CanAm Defender (4) 10mm

## Box Contains

PART	QTY	DESCRIPTION
A	1	JackDaddy
B	1	13" Adjustable Shaft
C	1	17.5" Adjustable Shaft
D	1	Foot
E	1	Roll Cage Mount Kit (2x Mounting brackets in 4 pieces)
F	1	8mmx65 Cam Lock (roll cage mount if chosen)
G	2	FRONT: 10mm x 70mm front jack nubs/shock bolt replacement. Nub 10mm x 1 <sup>3</sup> / <sub>8</sub> ".
H	2	FRONT: 10mm nylock flange nuts (front)
I	2	REAR: 12mm x 120mm rear jack nubs/shock bolt replacement. Nub 12mmx1 <sup>1</sup> / <sub>2</sub> ".
J	2	REAR: 12mm nylock nuts (rear)
K	2	5/16" x 1 <sup>3</sup> / <sub>4</sub> " wire shaft retaining pins
L	1	5/16" x 1 <sup>3</sup> / <sub>4</sub> " wire pin (for the foot)
M	4	3/8 " x 1 <sup>1</sup> / <sub>2</sub> " socket cap bolts (for cage mount if chosen)

## JackDaddy Rear Bracket Installation and Rear Shock Bolt replacement

1. Loosen rear shock bolt nuts.
2. Using a floor jack, jack your vehicle up so that there is no tension remaining on the rear shock bolts; you should be able to remove them by hand.
3. Remove the lower shock bolt.
4. Insert nub bolt through lower shock bolt holes, and ensure the nub itself is facing towards the front of the vehicle.
5. Ensure the nub holes are facing up and down for easier operation.
6. Secure with a 12mm nylock nut. Using a torque wrench, tighten to 110 foot-pounds of torque.

# JackDaddy Front Nub Installation and Front shock bolt replacement.

1. Loosen front shock bolt nut.
2. Using a floor jack (optional wooden block), jack your vehicle up so that there is no tension remaining on the front shock bolts; you should be able to remove them by hand.
3. Remove the lower shock bolt.
4. Insert nub bolt through lower shock bolt holes, and ensure the nub itself is facing forward of the vehicle.
5. Ensure the nub holes are facing up and down for easier operation.
6. Secure with a 10mm nylock nut. Using a torque wrench, tighten to 64 foot-pounds of torque

## Operating Instructions

1. **Only use JackDaddy when vehicle is in 4 Wheel Drive**
2. Measure: Set your JackDaddy next to the opposite tire that you are going to replace.
3. Measure: Note which hole sets the JackDaddy pivot head even with the bracket/nub.
4. Measure: Extend the JackDaddy by 2 more holes from the hole you noted in step 4; this will allow enough room not only to remove the flat tire, but also to replace a full aired up spare.
5. Measure: Place the 5/16" x 1 "
6. retaining pin into appropriate hole identified in step 5
7. Operate: Place the JackDaddy on the bracket/nub closest to the repair area/flat tire.
8. Operate: Ensure the longer side of the jack foot is always facing down.
9. Operate: When placing the JackDaddy pivot head on the nub/bracket be sure to secure the JackDaddy by pushing the 5/16" x 1 " retaining pin through the nub/bracket holes as well as the JackDaddy pivot head.
10. Operate: With the vehicle in 4 Wheel Drive, move forward or backward - depending on the orientation of your JackDaddy, always drive TOWARD your JackDaddy - with one foot on the gas one on the brake - until the vehicle is elevated and stable. You may also be able to do this step manually.
11. Operate: Put the vehicle in Park
12. Do your repairs!
13. Operate: With the vehicle in 4 Wheel Drive, move forward or backwards - in the opposite direction you traveled to jack up your vehicle, always drive AWAY from your JackDaddy - with one foot on the gas and one on the brake, slowly lower the vehicle back to the ground. This step can also be done manually.
14. Operate: Remove the 5/16" x 1 3/4" pin from the JackDaddy collar and remove the JackDaddy from the nub/bracket.



## CONTACT US

Phone: (801) 634-4321

Fax: (801) 955-1937

E-mail: [sales@tufftrailgear.com](mailto:sales@tufftrailgear.com)

URL: [www.tufftrailgear.com](http://www.tufftrailgear.com)

